

INSTRUCTIONS:

Model: QF-191 Fixture

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, OR INJURY

Lighted lamp is HOT!

WARNING- To reduce the risk of FIRE OR INJURY: Turn off all power and allow to cool before replacing lamp.

Lamp gets HOT quickly! Contact only switch/plug when turning on.

Do not touch lens, guard, or enclosure.

Keep away from materials that may burn.

Do not touch the lamp at any time. Use a soft cloth. Oil from skin may damage lamp.

Do not operate the luminaire with a missing lens or damaged shield.

Save these instructions.

Overview: Fixtures are designed for use with all WAC quick connect adapters. They may also be used on other manufacturers brand of quick connect (consult factory for compatibility).

Fixture is shipped partially assembled, some minor assembly is necessary.

1. Thread lens support rod into the threaded hole in the bottom of the fixture casting.
2. Use plastic washers on either side of the lens and insert onto the support rod.
3. Install threaded end cap, but do not tighten.
4. Allow lens to hang out of the way so that a lamp can be inserted.
5. Use an MR16-G (glass covered) lamp 50 watts max (12 or 24 volt depending on power supply).
6. Insert the lamp by aligning the pins with the socket holes, and gently pushing until lamp seats.
7. Rotate the lens so it is in front of the lamp and tighten the cap to maintain its position.
8. The fixture can now be inserted into the quick connect adapter. Rotate clockwise to install.

Installing the Quick Connect:

1. Insert the post of the quick connect into the quick connect adapter.
2. Thread the top half of the conical section until it seats with the adapter.
3. Adjust fixture position, use caution not to loosen the conical section.

Accessories:

May be used with Colored and Dichroic lenses with lens clip "LENS-16-CLIP"

